

## Level Gauges

### FUEL LEVEL GAUGES

#### Direct Reading (Mechanical)

**Application:** Truck or prime-mover fuel tanks, oil heating fuel tanks, agricultural fuel tanks.

| Tank Depth               | Mounting   | Part No. |
|--------------------------|------------|----------|
| 0.1 to 1.17m (4" to 46") | Horizontal | A.183.HU |
| 152mm (6")               | Vertical   | A.183.VH |
| 254mm (10")              | Vertical   | A.183.VA |
| 305mm (12")              | Vertical   | A.183.VC |
| 482mm (19")              | Vertical   | A.183.VE |
| 635mm (25")              | Vertical   | A.183.VF |

**Dimensions:** External diameter of flange 89mm (3½").

**NOTE:** For new installation of a fuel level gauge, flange mounting kit G-18010 is available.


**Installation:** Designed for installing into both fixed or portable fuel tanks, vertically or horizontally.

**Features:**

- \* Rugged construction.
- \* External surfaces corrosion protected by enamelled and chrome finishes.
- \* Direct coupling for reliable indication.
- \* Triple sealing of lens prevents moisture penetration.
- \* Silicone damped pointer, eliminates flutter.
- \* High tensile float arm.
- \* Brass float to prevent long term saturation.



A.183.VH



**We manufacture and stock a variety of Level Switches for Industrial use and for Mobile equipment.**

**Postal Address**  
Homersham Ltd  
P.O. Box 280  
CHRISTCHURCH 8015  
NEW ZEALAND

Phone: 03 3588309  
Phone: 0800 659888

Website: [www.homershams.co.nz](http://www.homershams.co.nz)

**Delivery Address**  
Homersham Ltd  
3 Homersham Place  
CHRISTCHURCH 8005  
NEW ZEALAND

Fax: 03 3582516  
Fax: 0800 659777

E-mail: [info@homershams.co.nz](mailto:info@homershams.co.nz)  
Section 4



Temperature  
Pressure